LaLOO Magnification Mirror

2811 C

Parts included in the box:

A

2 x 134 Wood Screws

в

2 x Wall Plugs

С ___

1 x Allen Key 4 x Set screws (2 exterior, 2 interior)



2 Wall Brackets



1 x Bottom Wall Flange (1 hole)

1 x Top Wall Flange (2 holes)



- Remove the bottom and top wall flanges from the packaging. (E, F)
- Using the allen key (C), remove the both wall brackets (D) from both wall flanges (E,F).
- 3.Slide the top wall flange (F) on to the mirror arm (G) with set screw on the bottom of the wall flange.
- 4.Install the bottom wall flange (E) on to the bottom end of the mirror arm (G) with set screw on the bottom of the wall flange.
- 5. Tighten the interior set screw of the bottom wall flange (E) to the mirror arm (G) using the allen key.
- 6.Measure 2¾" from the centre of bottom flange (E) to the centre of the top flange (F). Tighten interior set screw on top flange and secure to mirror arm (G).







- 7. Choose the desired height of the mirror on the wall. Mark the pilot holes for top and bottom flange at 2¾" apart. Ensure that markings are plumb.
- 8.Install plugs if there is no backing. If backing is provided, install wall brackets (D) with wood screws (A).
- 9.Install assembled mirror onto wall brackets (D) and tighten set screws on underside of top and bottom wall flanges (E, F) using the allen key. (C)



