

3M 94 Tape Primer

Primer Pens

Use a solution of 70% Isopropyl Alcohol and thoroughly clean the surface. Next, apply the primer to the surface using the cut-out above.

Crush here to release primer.



Foam Tip Applicator

The clear, colorless primer dries quickly, so to save primer and time, use the cut-out above and pre-mark where you will be placing your studs.

Directions:

1. Shake the pen well before using.
2. Squeeze the pen 1 inch in from the foam applicator to release the primer.
3. Once the primer has saturated the foam tip apply a thin, uniform coating to the surface using the cut-out above as a guide. This prevents wasting primer by only applying it on the area where the stud will be adhered.
4. Allow to dry before applying your studs. Dry time is about 5 minutes at room temperature.

NOTE: Extremely porous surfaces may require a second coat. Be sure to test your surface for compatibility before you begin.

Allow the primer to dry completely, which is usually accomplished in 5 minutes at room temperature, before applying tape. Special note: porous surfaces may require 2 applications for uniform coverage and good adhesion.